

# WPX-EM Series


Installation Instructions



## IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

- **DISCONNECT AC POWER SUPPLY BEFORE SERVICING.**
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure that the electrical wiring conforms to the National Electrical Code NEC® and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Do not use outdoors.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.
- Allow battery to charge for 24 hours before first use.
- For use with metal enclosed wiring systems.




## SAVE THESE INSTRUCTIONS!

Technical Support ■ (623) 580-8943 ■ [technicalsupport@barronltg.com](mailto:technicalsupport@barronltg.com)



### Wall Mount Installation (Fig. 2)

1. Remove screws using screwdriver to open front cover. (Fig. 1)
2. Knockout center and appropriate mounting screw holes on the backplate, adhere gasket on back of backplate.
3. Feed building power supply wires through the center hole, secure backplate to waterproof type junction box by screws.
4. Make proper electrical connections; see **Electrical Connections** section.
5. Push excess wire into junction box.
6. Attach battery connector to PCBA board.
7. Reinstall front cover to enclosure





### Side Mount Installation (Fig. 3)

1. Attach crossbar to junction box. Set the crossbar so that the longer blade is touching the waterproof type junction box.
2. Remove screws using screwdriver to open front cover. (Fig. 1)
3. Knockout the mounting hole on top or side of the unit, assemble the canopy on the unit. (Fig. 5)
4. Feed building power supply wires through the center hole, secure backplate to waterproof type junction box by screws.
5. Make proper electrical connections; see **Electrical Connections** section.
6. Fasten crossbar on J-Box by screws provided.
7. Adhere gasket to canopy, then fasten canopy to crossbar and against the wall.
8. Attach battery connector to PCBA board, reinstall front cover to enclosure.



### Ceiling Suspend Mount Installation (Fig. 4)

1. Preinstall mounting pipe and fix junction box on the mounting pipe (use local standard accessories).
2. Refer to side mounting instructions for the rest of the install.  
\*The difference is wiring knockout hole is on top of the housing.



### Electrical Connections

All electrical connections should be made inside the junction box.


Make electrical connections as follows:

#### 120-277VAC

White - Neutral

Black - 120-277VAC

### Wiring Diagram




### Max. Mounting Height

Model	Height
WPX-EM	20 ft

### Remote Heads Connection Instructions (Option)

1. Connect extended remote head wires to the remote wires using wire nuts. Yellow is positive (+) and the purple is negative (-). (Fig. 6)



### Operation

The battery in this unit may not be fully charged. After electricity is connected to the unit for at least 24 hours, then normal operation of this unit should take effect. To check, press the "TEST" button. The EXIT sign should stay illuminated by battery backup and the LED indicator will be turned off. Release the "TEST" button, LED indicator will be turned on.

In accordance with NFPA 101, your emergency lighting system must be tested monthly for a minimum of 30 seconds and annually for 90 minutes. Refer to your local codes for any additional requirements that may apply.

### Testing and Reporting Instructions (-G3/G3PRO models)

- When AC power is supplied to fixture, the unit will automatically initiate a self-test and self-diagnostic test as follows:
  - Verifies battery disconnection, charger board failure at every 5 seconds.
  - 1 minute self-testing every month.
  - 30 minutes self-testing on every 6 months after installation.
  - 90 minutes self-testing on every 12 months after installation.

2. Dual color LED lamp indicator shows the following status:

- Green color: On / Ready  
    Blinking: Testing
- Red color: (Service Alert)
- Service Alert LED Code (Red color LED lamp indicator)

●	One blink ON/pause (4 seconds)	Battery is not connect
●●	Two blinks ON/pause (4 seconds)	Battery voltage too low
●●●	Three blinks ON/pause (4 seconds)	Charger board circuit fault
●●●●	Four blinks ON/pause (4 seconds)	Transfer function failure
●●●●●	Five blinks ON/pause (4 seconds)	Integral lamp fault (option)
●●●●●●	Six blinks ON/pause (4 seconds)	Remote head's emergency lamp fault (option)
●●●●●●●	Seven blinks ON/pause (4 seconds)	LED strip failure (just for exit sign) (option)

**Note:** After solving the fault of emergency equipment, please press test button for 2 seconds then release to reset. LED indicator will show green.

3. "-G3/G3PRO" models also have a manual test function, press test button as follows:

Press test button once (within 2 seconds)	30 seconds discharge test
Press test button twice (within 2 seconds)	3 minutes discharge test
Press test button 3 times (within 2 seconds)	30 minutes discharge test
Press test button 4 times (within 2 seconds)	90 minutes discharge test
*Press and hold test button for 8 seconds	Fixture will leave network and reset itself

\*Only applies to "-G3/G3PRO" models. For use if you have problem to initiate provisioning or if you know the unit belongs to other Guardian G3 Network

### Networking Operations for "-G3/G3PRO" Models

Model with "-G3/G3PRO" suffix is our world winning design equipped with "wireless testing and reporting" features. Unit that has "-G3/G3PRO" suffix in its model number is capable of joining Guardian G3 emergency lighting management system. It will be part of a large testing system to be tested and report result wirelessly.

Once powered up and commissioning allowed, unit will automatically join Guardian G3 network and get provisioned. Upon the completion of the commissioning, unit will perform testing and report based on set schedules.

For more information about commissioning, configurations and testing, please visit website, <https://www.barronltg.com/guardian-g3-products.php> for details.