


IMPORTANT SAFEGUARDS READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

When using electrical equipment, basic safety precautions should always be followed including the following:

- **DISCONNECT AC POWER SUPPLY BEFORE SERVICING.**
- Installation and servicing of this equipment should be performed by qualified service personnel only.
- Ensure the electrical wiring conform to the National Electrical Code and local regulations if applicable.
- Do not mount near gas or electrical heaters.
- Equipment should be mounted in locations and at heights where it will not be readily subjected to tampering by unauthorized personnel.
- The use of accessory equipment not recommended by the manufacturer may cause an unsafe condition.
- Any modification or use of non-original components will void the warranty and product liability.
- Do not use this equipment for other than intended use.

SAVE THESE INSTRUCTIONS!




INSTALLATION INSTRUCTIONS

The low profile canopy light is designed to be mounted to a recessed J-box on ceiling, wall or can be pendant mounted using optional pendant mount adapter. Please consult with your lighting designer to obtain the optimum installation location.

Note: The LPC is not designed to be wired using surface mounted conduit.


1: Remove 4 cover plate screws.



2: Mount cover plate to junction box using the provided slots.



- 3: Electrical connection should be made inside junction box. Cap all unused leads to prevent shorting.
This fixture only accepts 120VAC.



WARNING! Do not allow the LPC to hang from the harness, this may cause damage to the circuit.

- 4: Mount bottom enclosure to the cover plate with 4 screws.

OPERATION

The low profile canopy requires no special handling. We do recommend routine inspections to visually verify that the fixtures are "ON" and emitting light. Any unit that is not functioning should be inspected and repaired or replaced.

TROUBLE SHOOTING

Canopy does not turn "ON"

1. Check incoming voltage, must be 120VAC only.
2. If any individual LEDs are "OFF" the LED light engine is defective. Please have the serial number off the light engine available when you contact technical support.